

Maxx Air Vent installation

When your RV is closed up or in storage it can get a musty stale odor inside. To help avoid this from happening you can invest in vent covers like Maxx Air vent covers. They are easy to install and well worth it. They fit over the existing vent covers on your RV and allow you to leave the vents open even when it's raining outside.

To install a Maxx Air vent start by placing the vent cover over the roof vent with the louver area facing the rear of the vehicle. Center the cover over the vent and use a pencil to trace the location of the slots in the MaxxAir Vent Cover's mounting flange on the roof. Position a mounting bracket on the roof so the slot in the bracket intersects one of the slot locations traced on the roof. The closer the brackets are to the outside corner of the roof vent frame the better it is.

Mark the location of the screw hole in the bracket onto the roof vent frame. Drill through the roof vent frame using a 3/16" drill bit. Put a carriage bolt up through the slot in the bracket and fasten the bracket to the vent wall using the small bolts provided. The small washer, lock washer, and hex nut should be placed on the inside of the roof vent frame wall. Install the three remaining brackets. Place the Vent Cover on the four carriage bolts and fasten using the large washers and hex nuts provided.

Now your RV has added ventilation and by placing one vent cover towards each end of the RV you have constant ventilation through your RV, even when it's raining.

Happy Camping,

Mark J. Polk

www.rveducation101.com